

Overview

Introduction

Trebuchets are fun to design, build and use. The Totally Trebuchet curriculum is a suite of self-paced tutorials, teacher-led lessons and project-based activities. This educational program provides an organized structure in which students and teachers acquire engineering skills and competencies through the design, construction, refinement and competitive use of model trebuchets. Totally Trebuchet lessons and activities demonstrate how math, science and engineering skills can be applied to the solution of an open-ended engineering challenge.

Content

Totally Trebuchet is an interdisciplinary engineering education exercise in which teams of students develop and employ transferable skills and competencies in one or all of the following areas:

- Science
- Engineering
- Mathematics
- Engineering Drawing
- Communication and Careers

The Build Report

The Build Report is the "Essential Element" or "Deliverable" expected from students who participate in this engineering education exercise. The Build Report includes:

- Solid Models, Working Drawings and COSMOS analysis that graphically describes trebuchet components and assemblies
- Papers, presentations and research.
- Results of using mathematical models to describe trebuchet parts or performance.
- Data from "Full sized" design iterations modeled on the TrebStar™ trebuchet simulator.
- Descriptions of the cost, weight and material properties of trebuchet parts and assemblies.
- Logs or diaries that chronicle the process of designing, constructing and testing trebuchets.
- Class Notes
- Trebuchet work sheets and other educational aerobics for the mind.

Assessment

Educational success is best evidenced by a student's ability to clearly articulate what they know and are able to do. The measure of a student's participation in the Totally Trebuchet program of activities is evaluated in these three ways; Demonstrations of their competencies and skills, The quality of their build report and the caliber of their engineering performance in the Totally Trebuchet challenge.

Educational Components

Totally Trebuchet is a complete set of educational tools and text materials designed to provide a comprehensive introduction to science, math and engineering studies.

• GEARS-IDSTM Trebuchet Kit and Construction Manual

Rugged and re-configurable structural components designed to withstand the yearly demands of classroom service. These materials are organized in a storage container for easy classroom management.

• <u>D&M SolidWorksTM Tutorials</u>

A self-paced CAD tutorial and video disc presentations that allows teachers and students to quickly and easily create a fully functioning trebuchet solid model using the same structural components found in the GEARS Totally Trebuchet kit.

• <u>TrebStarTM Trebuchet Computer Simulation</u>

This easy to use simulation mathematically models trebuchet performance and efficiency. It allowing teachers and students to quickly and accurately create dozens of trebuchet design iterations.

• Will It Break? By Donald Siano

A clear, concise introduction to the engineering and analysis needed to safely design and build small, medium and large-scale trebuchets. Written and explained by a professional engineer with a passion for hurling!

• GEARS-IDSTM Totally Trebuchet Curriculum

An integrated program of science, mathematics and engineering studies organized around an engineering challenge. Students work in teams to produce an engineering build report that chronicles the design, construction and competitive use of working trebuchets. The curriculum materials are divided into eight chapters and mapped to national education standards.

- 1. Building the Trebuchet Team: SCANS: Tools for Success in Team Based Projects
- 2. Talking Trebuchets: Engineering Communication
- 3. Trebuchet Mechanics
- 4. Trebuchet Math
- 5. Trebuchet Science and Engineering
- 6. Improving Trebuchet Performance: Design a machine to win
- 7. Totally Trebuchet: The Game
- 8. The Trebuchet Build Report: The Purpose of Engineering

Chapter Outlines

This program of studies creates educational excitement and provides the tools students need to:

- Work cooperatively and effectively as a member of an engineering team
- Research and communicate information
- Use mathematics, mechanics and science skills to improve engineered systems.
- Understand and use engineering methods.

Organize instructive engineering and design challenges.

The program also provides ready made work sheets, assessment materials and prepared rubrics mapped to national education standards.

Chapters

1.0 Building the Trebuchet Team

SCANS: Tools for Success in Team Based Projects

- 1.1 Lessons
 - 1.1.1 SCANS: Shared competencies for engineering teams
- 1.2 Worksheets and Activities
 - 1.2.1 SCANS presentations
 - 1.2.2 Self Assessment Activity

2.0 Engineering Communication: Researching Trebuchets

- 2.1 Lessons
 - 2.1.1 Developing Technical Literacy and Sharing Knowledge
- 2.2 Worksheets and Activities
 - 2.2.1 Research
 - 2.2.2 Outline
 - 2.2.3 Write
 - 2.2.4 Present
 - 2.2.5 Evaluate
- 2.3 Assessment
 - 2.3.1 Papers and presentations
 - 2.3.2 Student authored guizzes
 - 2.3.3 Build Report: Research summaries, outlines, papers and presentations.

3.0 Trebuchet Math

3.1 Lessons

- 3.1.1 Perimeter, area and volume
- 3.1.2 Density and weight
- 3.1.3 Angles: Improving range

3.2 Worksheets and Activities

- 3.2.1 Perimeter area and volume of the 6x9 plate
- 3.2.2 Compare the densities of the counterweight and projectile
- 3.2.3 How launch angles affect range

3.3 Assessment

- 3.3.1 Calculating perimeter, area and volume of the sine triangle
- 3.3.2 Calculating weight
- 3.3.3 Build Report: Class Notes and worksheets

4.0 Trebuchet Mechanics

4.1 Lessons

- 4.1.1 Units of measuring and converting
- 4.1.2 Will it break? Evaluating loads and limits on the trebuchet axle
- **4.1.3** The mechanics of threaded fasteners: Tensile strength and simple machines.

4.2 Worksheets and Activities

- 4.2.1 Testing monofilament fishing line for tensile strength and stretch
- 4.2.2 Specifying and selecting threaded fasteners.
- 4.2.3 Analyzing and estimating loads on trebuchet axles.
- 4.2.4 Using SolidWorksTM CosmosTM to analyze axle stress.

4.3 Assessment

- 4.3.1 Calculating the mechanical advantage of the trebuchet lever arm.
- 4.3.2 Calculating the deflection of a loaded axle
- 4.3.3 Build Report: Evidence of Class Notes and Worksheets.

5.0 Trebuchet Science and Engineering

5.1 Lessons

- 5.1.1 Unbalanced forces acting on the beam
- 5.1.2 Energy and work: The trebuchet counterweight
- 5.1.3 Velocity, the trebuchet design objective
- 5.1.4 Acceleration: Changes in projectile velocity
- 5.1.5 Efficiency: The difference between the energy of the falling counterweight and the energy of the hurled projectile.

5.2 Worksheets and Activities

- 5.2.1 Determine the potential energy of the counterweight.
- 5.2.2 Determine the work produced by the falling counter weight
- 5.2.3 Determine the projectile range based on the velocity and angle of launch.
- 5.2.4 Calculate the trebuchet's efficiency (*Gross*)
- 5.2.5 Creating and using spreads sheets

5.3 Assessment

5.3.1 Build Report: Evidence of experiment, record keeping and mathematical and simulation analysis.

6.0 Improving Trebuchet Performance: Design to Win

6.1 Lessons

- 6.1.1 The iterative process of design: Asking and answering essential questions
 - 6.1.1.1 What factors affect the hurling range of a trebuchet and how can they be controlled?
 - 6.1.1.2 What factors affect hurling repeatability or precision and how can they be controlled?

6.2 Worksheets and Activities

- 6.2.1 Iterative testing and analysis: Using the TrebStarTM Simulation to model "Virtual" trebuchet performance
- 6.2.2 Iterative testing and analysis: Empirical testing and record keeping.
- 6.2.3 Use a spreadsheet to record and predict cost and weight.
- 6.2.4 Calculating and comparing scoring strategies

6.3 Assessment

6.3.1 Build Report: Evidence of:

Iterative experimentation and record keeping Mathematical models or spread sheet analysis TrebStarTM simulation analysis.

7.0 Totally Trebuchet: Game Day

The Final Answers to the Essential Questions

7.1 Lessons

7.1.1 The Totally Trebuchet Game description: Know the rules

7.2 Worksheets and Activities

7.2.1 The how's and whys of failure and success: Game day analysis

7.3 Assessment

7.3.1 Calculating trebuchet precision and accuracy

8.0 Maintaining the Trebuchet Build Report: Purpose of Engineering

8.1 Lessons

- 8.1.1 Build report organization, maintenance and expectations
 - 8.1.1.1 Chronological organization
 - 8.1.1.2 Visualization: Solid models and working drawings
 - 8.1.1.3 Worksheets and Activities
 - 8 1 1 4 Class Notes

8.2 Assessment

8.2.1 Build Report Rubric: Assessing and evaluating the Build Report

Appendices: Manuals and Resources

<u>D&M SolidWorks</u>TM <u>Tutorials</u>

A self-paced CAD tutorial and videodisc presentations that allows teachers and students to quickly and easily create a fully functioning trebuchet solid model. This tutorial makes use of the structural components found in the GEARS Totally Trebuchet kit.

Building the GEARS-IDS Trebuchet

A self-paced assembly tutorial that allows teachers and students to quickly and easily construct a working trebuchet model. This model has eight adjustable design parameters and is constructed from parts supplied in the GEARS Totally Trebuchet kit.

Note: These eight chapters and the lessons they contain are stand alone educational resources. There is no intention on the part of the author to imply that these chapters or lessons be presented in any particular sequence.




Totally Trebuchet Construction Guide

An Illustrated Assembly Manual

Introduction

Medieval engineers designed and built trebuchets capable of accurately hurling large masses over distances spanning hundreds of feet. The GEARS-IDS™ trebuchet lacks the power of the historic siege engines, but the precision and accuracy of these mechanical models are just as impressive, and they are much safer to operate within school classrooms and foyers!



incrementally improve the trebuchet's performance.

Designing and building trebuchet models for use in engineering activities is an excellent way to develop skills and competencies in science, engineering and mathematics.

Totally Trebuchet builders need to carefully consider the 8 design parameters that affect the trebuchet's performance.

The trebuchet is a design problem with multiple solutions. It is a wonderful opportunity to apply the iterative process of experimenting, building, modifying and testing design decisions. This process results in the creation of a data base of engineering knowledge and experience used to

Design parameters refer to the variable trebuchet lengths and masses that can be changed in an effort to optimize the performance of the machine with respect to hurling (*Throwing*) distance and efficiency

8 Design Parameters

Lengths

- 11 Counter Weight Arm Length (Short Arm)
- 12 Throwing Arm Length (Long Arm)
- 13 Projectile Sling Length
- 14 Counter Weight Hangar Length
- 15 Axle to Base Height


Masses

m1 Counter Weight Mass

m2 Projectile Mass

mb Beam Mass

Sketching Exercise: Sketch this trebuchet schematic and label the 8 design parameters. Use this sketch to record changes you make as you operate, test and improve the performance of your working trebuchet model



Build a Data Base of Knowledge and Experience

Before beginning any project, it helps to have a sense of what the beginning, middle and end of the project might look like. It also helps to become familiar with the look, feel and identification of the parts. For best results, read through this document and identify the parts prior to building the trebuchet.



Note: A team of 2 or 3 people can build the Trebuchet quickly and efficiently. Each team member can build 1 of the three subassemblies from which the trebuchet is constructed. (2 frames, 1 lever arm assembly)

Performance Tip. Engineering is a team sport. Be an engineering MVP. Accept and commit to completing specific responsibilities. Always remember to return the tools and parts to their appropriate storage containers.

Build-Test-Modify: A Description of The Trebuchet Activity

- 1. Obtain and organize the necessary tools and materials (Listed below)
- 2. Complete a cursory review of this document to learn what needs to be done and what will be needed to do it.
- 3. Create a trebuchet construction team and assign responsibilities for constructing the three major subassemblies.
- 4. Build the subassemblies and integrate them into a working trebuchet.
- 5. Measure and record the design parameters of the trebuchet you build. These include sling lengths, counter weight arm lengths, launch angles, throwing arm lengths, axle heights, counterweight masses, projectile masses and beam mass. Make a sketch that clearly illustrates the dimensions and components of your trebuchet model.
- 6. Use the TrebstarTM trebuchet simulator to create multiple design iterations and optimize the dimensions and values of the trebuchet parameters.
- 7. Practice using the trebuchet and refine the range and accuracy through iterative changes and testing.
- 8. Obtain and read the Totally Trebuchet Engineering Challenge rules and description.

Note: The GEARS-IDS™ Totally Trebuchet kit includes the components needed to modify the values or dimensions of all 8 of the listed design parameters. However, We strongly suggest that the Totally Trebuchet games and activities all be played using only the 12 oz. counterweight included in the kit.

Caution: The sling release mechanism on the end of the throwing arm is a sharp pointed device. Both the throwing arm and the projectile are highly energized, fast moving and therefore capable of causing injury. To protect against eye injuries- <u>Always wear safety glasses when working on, testing or using trebuchet models.</u>

Organize the Tools and Materials

The trebuchet can be assembled with minimal frustration by taking the time to read through the directions. Prepare the necessary tools and materials before beginning the assembly.

Required Tools

Safety Glasses #2 Phillips Head Screwdriver 5/16" Combination Wrench 3/8" Combination Wrench Needle nose pliers

Structural Metal Components

5/64, 6/32, 1/8 Allen Wrenches or Hex Keys Dial Calipers 25' – 100' Tape Measures 12" Rule

Materials

Refer to the end of this text for an illustrated parts catalog.

Qty		Qty.	
1	6x9 Flat Plates	50	#10-24 x 1/2" PH Machine Screws
4	13 Hole Angles	6	#10-24 x ³ / ₄ PH Machine Screws
2	7 Hole Angles	50	#10-24 Nuts
2	11 Hole Flat Bars	100	#10 Flat Washers
2	7 Hole Flat Bars	50	#10 Split Ring Lock Washers
2	Sine Triangles	10	#10 Fender Washers
4	90 Degree Fish Plates	4	#10-24 x 1" PH Machine Screws
1	180 Degree Fish Plates	2	#6-32 x ½" ph machine Screw

Machined Parts

Qty.

1 3" Hex Wheel 1 4" x 3/16 Axle

1 1-1/2" x 3/16 Axle

1 7/16" x 3/16" bore Hex Adapter

1 ½" Shaft Collar

6 3/16" Shaft Collars

1 Mast Holder and 2-#10-24 set screws

Miscellaneous Supplies and Materials

Qty.

2

Hardware

1 12 Ounce Lead Ball Fishing Weights

2 Wood Balls, 1" Diameter

#6 Flat Washers

#6 Hex Nuts

2 Wood Balls 1-1/4" Diameter

2 Wood Balls 1-1/2" Diameter

10' Fishing Line

1' 1/16" Welding Rod

2 18"x 5/16" Dowels

1 3/8" Hose Clamp

Performance Tip. Use flat washers whenever possible to evenly distribute the clamping force of the machine screw assemblies. Use split ring lock washers or nylon locking nuts to prevent machine screw fasteners from loosening during use.

Model Trebuchet Construction Illustrated


Support Frames

Step One: Attach 90 Degree Fish Plates

Necessary Components

Qty. Description

- 1 Rectangular 6 x 9 plate.
- 3 #10-24 Phillip head machine screws, nuts and washer assemblies.
- 2 90 degree fishplates



Performance Tip. Lightly tighten all machine screws and nuts at this time. The fasteners can be fully tightened during final assembly.

Procedure

Use #10-24 x 3/8" Phillip head machine screws to attach the 90 degree fish plates to the end holes on the second row of the 6x9 base plate. Use split ring locking washers between all the hex nuts and flat

washers. The fishplate is secured to the end hole in the second row.




Fig. 2

9

Note: Be certain to align the orientation of the long hole in the 90 degree fish plate as illustrated in figure 2.

A Math Moment: Perimeter and Area

Make a copy of the working drawing for the 6" x 9" Base Plate found at the end of Chapter 3.0 Trebuchet Math. Using the dimensions given on the drawing, calculate the following:

- 1.) The perimeter of the 6"x 9" Base Plate.
- 2.) The total surface area of the 6"x 9" Base Plate.
- 3.) The combined surface area of all the holes in the 6"x 9" Base Plate
- 4.) The total surface area of aluminum. Hint: This would be the total surface area less the combined area of the holes.

Note: Perform all the calculations directly on the copy of the worksheet and keep this work chronologically organized in your build report.

For a complete explanation and answers to these problems refer to the Chapter <u>3.0 Trebuchet Math</u> lessons dealing with 3.1.3-Perimeter, 3.1.4-Area and 3.1.5-Volume.

Support Frames continued

Step Two: Attach the 13 Hole Angles

Necessary Components


Qty. Description

- 2 13 hole angles
- #10-24 x ½" Phillip head machine screws, nuts and washer assemblies.

Fig. 3 Note: Flat washers are used with screws in order to evenly distribute the clamping force generated when the screw is tightened. See the Science Second below.



Use #10-24 x 1/2" Phillip head machine screws to attach the 13 hole angles to the fish plates. Use split ring locking washers between all the hex nuts and flat washers.




Note: Be certain to align the orientation of the 13 hole angles as shown in figures 3 and 4. Mount the 13 hole angles outboard of the fish plates as illustrated.

Science Second

A machine screw is a simple machine. It can be described as an incline plane wrapped around a cylinder.

Find the Mechanical Advantage of the Screw

1.) Calculate the difference in height between two adjacent screw threads.



2.) Divide by the perimeter of the cylinder. This will yield an approximation of the theoretical mechanical advantage of the screw thread. The information on the right indicates that a #10-24 Machine Screw creates a TMA (force multiplier) of 11- 12 times the applied force.

For a more complete explanation of this problem refer to the Chapter 4.0 Trebuchet **Mechanics**

#10 –24 Machine Screw Specifications

Root Diameter = 0.150" +/-

Root Circumference = $0.150 \times 3.14 = 0.471$ "

Thread Height/pitch = 1/24" or 0.041"

(TMA) Theoretical Mechanical Advantage

TMA = 0.471"/ 0.041" = 11.48


Support Frames continued

Step Three: Attach the Cross Bracing

Obtain these components:

Qty. Description

- 1 11 hole flat bar
- 1 7 hole flat bar
- 5 #10-24 x ½" Phillip head machine screws, nuts and washer assemblies.
- 2 #10-24 coupling nut
- 2 #10-24 x 3/8" machine screw and washer



Procedure

Use two #10-24 x 1/2" Phillip head machine screws to attach the 11 hole flat bar across the 13 hole angles.

Use one $\#10-24 \times 1/2$ " Phillip head machine screws to attach the 7 hole flat bar diagonally across the 11 hole flat bar. Use one $\#10-24 \times 3/8$ " machine screw and flat washer with a #10-24 coupling nut to attach the 7 hole flat bar to the right side 13 hole angle as shown in figure 5.

Fasten an additional $\#10-24 \times 3/8$ " machine screw and flat washer with a #10-24 coupling nut to the left side 13 hole angle as shown in figure 5.



Note: Be careful to align the orientation of the 11 hole flat bar to the 13 hole angles as shown in figures 5 and 6. Mount the 7 hole flat bar diagonally as shown in figure 6. Attach the #10-24 coupling nuts to the end holes of the angles as shown in figure 6.

Fig. 6


Support Frames continued

Step Four: Attach the Sine Triangle

Obtain these components:

Qty. Description


- 1 Sine Triangle
- 6 #10-24 x 3/8" machine screw and washer



Procedure

Use two #10-24 x 3/8" Phillip head machine screws and flat washers to attach the sine triangle to the coupling nuts as shown in figure 7.

Step Five: Repeat the Procedure for the Other Side



A Math Moment: Equilateral Triangles

The GEARS-IDS™ flat bars have 0.190" diameter holes drilled 0.50" on center. This means the center of each hole is ½ " apart. The diagonal bracing of the trebuchet forms a triangle whose 3 sides are each 7 holes long! The three sides are the same length and they form an equilateral triangle. *Equi* means equal and *lateral* means side. This is an equal-sided triangle.

Make a hand drawn sketch of the side view of the support frame and include all the dimensions needed to understand it's construction. Use this sketch and the paper it is drawn on to complete the following 5 exercises. Remember to keep copies of this work in your build report.

- 1. Determine the measure of the included angles of this equilateral triangle?
- 2. What is the perimeter of the equilateral triangle formed by connecting the hole centers?
- 3. Determine the approximate area of the triangle formed by connecting the hole centers.
- 4. Make an accurate drawing of this triangle using a pencil, paper and a rule.
- 5. Measure the height of the triangle you drew.

Throwing Arm Assembly

Step One: Make up the Axle Assembly (figure 10)

Necessary Components

Qty. Description

- 1 3/16" diameter x 4" long axle.
- 1 Stainless steel hex adapter.
- 6 3/16" (bore) shaft collars.
- 7 3/16" fender washers



Fig. 9

The completed throwing arm assembly



Procedure

Obtain the necessary components to construct the axle assembly illustrated in figure 10. Use only the hex adapter and set the remaining components aside for later use.

Step Two: Secure the 3" Wheel and Hex Adapter (Figure 11)



Necessary Components

Qty. Description

- 1 Stainless steel hex adapter.
- 1 3" Wheel
- 1 ½" (bore) Shaft Collar

Procedure

Fasten the 3" wheel to the hex adapter using the ½" shaft collar. Secure the shaft collar to the hex adapter using the shaft collar set screw.

Fig. 11

Mechanical Insight

Note: The shaft collar set screw is specified as follows: 1/8 hex x $\frac{1}{4}$ -20 x $\frac{1}{4}$ ". Following the specification in order; this means the set screw requires a 1/8" allen key wrench, the nominal screw diameter is $\frac{1}{4}$ ", the thread pitch is 20 threads per inch (tpi) and the screw is $\frac{1}{4}$ " long."

Throwing Arm Assembly continued

Step Three: Counter Weight Arm (figure 12)

Necessary Components

Description Oty.

- 7 hole angles.
- #10-24 x 3/4" machine screws and washers




Fig. 13




Fig. 12

Procedure

Obtain the necessary components to construct the counter weight arm assembly illustrated in figure 12. Note: An orthographic (front) view of the counter weight arm assembly is shown in figure 13. Use this view to

obtain

proper orientation of the throwing arm, 3" wheel and fasteners.

A Math Moment: Concentric Circles

Concentric circles share the same centers. The GEARS-IDS™ 3" wheel pictured in figure 14 has sets of 8 holes equally arrayed around four concentric circles. Approximate layout circles are pictured in the figure 14 illustration.

Create a sketch of the wheel shown in fig. 14. Using dial calipers and a calculator, determine the diameters of the 4 concentric circles on which the holes are arrayed.




Fig. 14

The sketch should show all dimensions needed to create a SolidWorks model of the wheel. Include both a front (shown) and side view of the 3" wheel in order to provide all the dimensional information needed to model the wheel.

Hint: Since it is impossible to measure from the exact center of the holes (The centers are not there), it will be necessary to derive the distance from the center of the wheel to the center of each hole. It is also necessary to know the diameter of the wheel and the diameter of the small holes in order to derive the diameter of the concentric layout circles.

Throwing Arm Assembly


continued

Step Four: Counter Weight Assembly (figure 14)

Necessary Components

Qty. Description

- 1 3/16" x 1-1/2" axle.
- 2 3/16" (bore) shaft collars
- 1 180 degree fish plate
- 4 3/16" flat washers
- 1 #10-24 x $\frac{1}{2}$ " Phillip head machine screw and nut
- 1 12 ounce lead counter weight




Procedure

Obtain the necessary components to construct the counter weight assembly illustrated in figure 15.

Connect the fishplate to the lead counter weight using the #10 screw, washers and nut as shown in the illustrations (*Top and left*).

Attach the fishplate and counter weight assembly to the end of the counter weight arm by passing the 1-1/2" axle through the arm members and fishplate. Capture the fishplate inboard between the two 7 hole angles. The fishplate should hang in between the 7 hole angles in such a way as to swing freely through 270 degrees of revolution or more. The fishplate should be firmly





Note: In order to mount the fishplate to the counter weight, it may be necessary to reconfigure the shape of the brass wire ring on the counter weight. This can be accomplished using a pair of needle nosed pliers and/or a small screwdriver.

A Science Second: Density

The counter weight is a lead sphere measuring approximately 1-1/2" (38mm) in diameter and weighing approximately 12oz. (340g). The average weight density of a homogeneous material can be calculated by the following formula;

$$Density = \frac{Weight}{Volume} = \frac{\text{Weight is pounds}}{\text{Volume is in}^3} \qquad \text{Or} \qquad \frac{\text{Mass is in grams}}{\text{Volume is in cm}^3}$$

A Science Second: Density continued

Calculating the counterweight density involves these steps;

- 1. Calculate the volume of the counterweight sphere
- 2. Determine the weight of the lead sphere in pounds
- 3. Divide the weight of the lead sphere by the volume of the lead sphere
- 1.) The volume of a sphere can be calculated using this formula;

Volume Sphere =
$$\frac{4}{3}\pi * r^3$$

The volume of the lead counterweight can be found by making these substitutions;

(Pi)
$$\pi$$
 = 3.14 (Radius) \mathbf{r} = 0.75" or 0.062' of lead sphere in inches and in feet.

thus

Volume Sphere =
$$1.75 in^3 = 0.001 ft^3$$

2.) Convert the weight of the sphere from ounces to pounds

Since there are 16 ounces in 1 pound, and the lead sphere weighs 12 ounces the conversion looks like this;

$$\frac{\text{Weight of Sphere in oz}}{16 \text{ Ounces/pound}} = \frac{12oz}{16oz/lb} = 0.75 lbs$$

3.) Divide the weight of the lead sphere by the volume of the lead sphere.

$$Density = \frac{Weight}{Volume} = \frac{0.75lbs}{0.001 \, ft^3} = 750 \, lb \, / \, ft^3$$

This value is about 94% correct. Cast lead is actually reported to weigh approximately 708 lbs/ft³. The difference in our calculated weight density may be due to cumulative errors in;

- 1. Rounding errors
- 2. Errors in measurement since the lead sphere is not perfectly round.
- 3. Non homogeneous material since we cannot know the purity of the lead material.

Caution: Lead is a dense (heavy) metal. Care should always be taken when handling lead. Always wash your hands after handling lead and never eat food while you are handling lead.

Throwing Arm Assembly

continued

Step Five: Throwing Arm Assembly (figure 16)

Necessary Components

Qty. Description

- 1 5/16 x 18" wood dowel.
- 1 Shaft retainer with #10-24 set screws
- 2 1/8"hex key set screws $\frac{1}{4}$ -20x $\frac{1}{4}$ "
- 2 #10-25 x ½" Phillip head machine screws




Fig. 17

Procedure

Fig. 16

Secure the shaft retainer to the 3" wheel using 2 #10-24 x ½" machine screws and washers as shown in figures 16-17. Hex nuts are not required since the shaft retainer has threaded holes to accept the #10-24 machine screws.

Fasten the 5/16" x 18" wood dowel to the shaft retainer using the #10-24 set screws as shown.

The wood dowel has a 1/8" hole drilled in the top. Do not insert the end with the 1/8" hole.

Note: The builder must determine the wood dowel length. There are many ways to optimize the wood dowel length. Trial and error is one method. A better

method is using the $TrebStar^{TM}$ simulator to make and test iterative designs in an effort to optimize both the dowel length and the projectile length.

A Science Second: Unbalanced Levers

F2 = 0.032 Newtons F1 = 3.36 Newtons

D2 = 0.28 Meters D1 = 0.07 Meters

Viewed in simplest terms, a trebuchet is an unbalanced lever. In the example to the left, we imagine that the lever arm has no mass (*Thus no weight and no inertia*). Ignoring the lever arm allows us to write a simple mathematical expression to determine the force that causes the arm to rotate about the fulcrum

On a separate paper, sketch the graphic on the left and use the information provided to calculate the following;

- 1. Net Torque, or net turning force acting to rotate the (*Imaginary*) trebuchet arm about the fulcrum.
- 2. Direction of rotation of the arm.

<u>Neatness and completeness matter</u>. Remember to record this exercise in your build report.

Throwing Arm Assembly continued

Step Six: Throwing Arm Release Pin (figure 18)

Necessary Components

Qty. Description

- 1 Hose clamp.
- 1 Paper Clip or 4" length of wire rod






Procedure

Fashion the paper clip or wire rod into the release pin shape pictured in figure 20.

Mount the release pin to the throwing arm by passing the bent wire through the 3/32" hole in the wood dowel. Secure the release pin using the hose clamp as pictured in


figure 19.

Note: Trebuchet performance and range can be improved by fastening the release pin to the throwing arm using either duct tape, tie wraps or tightly wound elastic bands instead of the hose clamp. Remember that even a small amount of additional weight at the end of the throwing arm will decrease the net torque produced by the counterweight and reduce the speed and thus range of the projectile.




The Sling and Projectile Assembly

Fashion an eye on the end of the sling using a surgeons loop. (shown below)





- 1. Make a large loop in the end of the leader.
- 2. Using the loop, make another loop and hold with thumb and forefinger.
- 3. Go thru the loop twice.
- 4. Pull tight.
- 5. Trim ends.



Attach the snap swivel to the sling using a fisherman's knot. (Shown above)

Open the snap swivel hook and pass it through the eye of the cotter pin.





Integrating the Subassemblies

Attaching the Throwing Arm to the Support frames

Step One: Select the axle assembly components from step one. Attach the throwing arm by passing the axle through the top hole in the sine triangle and sliding the fender washers and shaft collars in the order illustrated in figure 21.




Fig.21 A top view of the axle assembly




Fig. 22 The completed trebuchet


Hurling: Preparing for Competition

Operating, Testing and Improving Performance

SAFETY FIRST: <u>Always wear safety glasses when you are using the trebuchet</u>. The slip hook on the end of the trebuchet is pointed and it can pose a hazard when it is standing still or while the trebuchet is being used.

Operating the Trebuchet (*Hurling*)

Hurling is a simple matter. Attach the sling and projectile ball to the slip hook on the end of the throwing arm. Pull the throwing arm, sling and projectile to the fully cocked position while holding on to the projectile ball. Hurl the projectile by letting go of the projectile ball while keeping your hand clear of the falling counterweight.



Testing and Improving the Trebuchet

Building the trebuchet described in this text, and hurling the projectile is only the beginning of this engineering exercise. The real challenge posed by this activity is how to improve the range, precision and accuracy of the trebuchet.

Specific instructions for how to obtain the best hurling results have been deliberately omitted from these instructions. Careful consideration should be given to factors that affect the range, precision and accuracy of the trebuchet. Use what you have learned to test and analyze the trebuchet's performance.

Engineering Improvements: Some Good Questions About Trebuchet Performance

The following questions deserve engineering consideration. In some cases the answers may require the design and construction of additional components in order to improve the range, accuracy and precision of a trebuchet. *Example: A projectile slide can increase precision and can be made from oak tag and tape.*

What are the rules of the Totally Trebuchet game?

What are the best design considerations and strategies to employ in an attempt to succeed at the game? What are the relationships between the 8 design parameters, and how do they affect performance? What is the effect of changing the angle at which the sling and projectile leave the throwing arm? How does the initial travel of the projectile ball affect range, accuracy and precision? What are the consequences of developing a consistent release method and point of release? Why make the effort to maintain a consistent and repeatable firing position with respect to the target? How does "Play" or looseness in the trebuchet mechanism affect performance?



Assessment: Totally Trebuchet Construction and Use

Evaluating Acquired Skills and Competencies

The ability to manage resources and information is an ingredient for success in most careers. The SCANS listed below articulate the skills and competencies necessary for both independent and group achievement. A person without these essential skills and competencies has little to contribute to a team of people whose ultimate success depends on the application of their collective abilities.

Apply Technology
Acquire Data
Evaluate Data
Access and Use Information
Work Cooperatively
Interpret Textural Information
Interpret Visual Information
Maintain Materials/Equipment

M
Pr

Create
Design
Provide Leadership
Support Leadership
Negotiate
Organizational Skills
Share Knowledge and Skills
Maintain Files/Records
Process Information

Manage Time
Appropriate Decisions
Correct Performance
Improve Systems
Responsibility
Self-management
Access and Use Resources

Trouble Shoot

A Word About Project Based Learning and Authentic Assessment

Like the medieval trebuchet engineers before them, small teams of students travel the path of discovery by asking and answering relevant questions about the physical principles and mechanics that govern the operation of these machines. The questions they ask, and the ways in which they attempt to develop answers provide authentic opportunities to construct new knowledge. The build report or engineering journal is an excellent way for students to document and present what they know and are able to do. The build report also provides the evidence necessary to assess the results of their journey of discovery.

Project based learning provides opportunities for students and teachers to construct competencies and skill sets through a process of inquiry and discovery. The skills, knowledge and experiences acquired through participating in project-based learning activities depends in part on:

- The participants' ability and desire to frame relevant questions and by the reward and satisfaction they derive from the answers they construct.
- The demands and expectations of the coursework

Carefully designed projects, products and activities include opportunities for: *authentic learning*, acquisition of central concepts, motivation and interest, using essential tools and developing essential skills, multiplicity of solutions, performance based assessment, collaboration.

The assessment rubric on the following page is calibrated to measure the degree to which participating students take advantage of the opportunities presented in the Building the Totally Trebuchet construction activity.

Assessment Rubric: Building the GEARS Trebuchet

This rubric is offered as an example. Teachers and students are encouraged to create assessment tools that reflect their needs and expectations.

Required Skill or Competency	Meets or Exceeds this Requirement	Meets Some of this Requirement	Meets little or None of this Requirement
	Score 4-5 pts	Score 2-3 pts	Score 0-1 pts
Successfully constructs the working trebuchet by following the example described in the text and illustrations provided.			-
Demonstrates organization and management skills and uses the tools and materials responsibly.			
Participates in an effort to operate test and improve the range and precision of working trebuchet.			
Can accurately measure and record the 8 design parameters.			
Produces clearly labeled sketches detailing the trebuchet components and dimensions.			
Shows evidence of using the Trebstar TM trebuchet simulator to create multiple design iterations.			
Records the experimental methods used to improve the range and accuracy of the trebuchet.			
Demonstrates a working understanding of the Totally Trebuchet Game			
Constructs a trebuchet capable of hurling a 1" diameter wood ball a distance of 20" into a 20" target circle 5 consecutive times.			



The Parts Catalog

Use this parts catalog to identify and organize the Totally Trebuchet parts and materials. This information can also serve as a guide for creating spreadsheets to calculate and analyze the relationships between the cost, weight and performance of various trebuchet configurations. Examples of these relationships might be:

- Hurling range vs. cost or weight
- Precision and accuracy vs. cost or weight
- Cost vs. weight

Note: The cost column was deliberately left empty to encourage teachers and students to copy this catalog and make up their own cost figures. This would allow for differences in results from class to class or from year to year.

Image	Qty.	Description	Weight Approximate	Cost
	1 pc.	180 Degree Fishplate Used as a swing arm attachment for the counterweight	1.5 grams	
	5052 Aluminum		0.051 ounces	
000	2 pc.	11 Hole Flat Bar Used as cross bracing	17 grams	
33.3.3.3.3.3.3.3.3.3.3.3.3.3.3.3.3.3.3.3	304 Stainless Steel	for the trebuchet support frames	0.6 ounces	
Control of the Contro	2 pc.	7 Hole Flat Bar Used as cross bracing for the trebuchet support frames	11 grams	
	304 Stainless Steel		0.39 ounces	

1 pc. 5052 Aluminum	6 x 9 Plate Used as the mounting base to support the trebuchet structure	164 grams 5.78 ounces
4 pc. 5052 Aluminum 2 pc. 5052 Aluminum	90 Degree Fish Plate Used to affix the support frames to the 6x9 plate Sine Triangle Used to support the throwing arm assembly	1.5 grams0.051 ounces12 grams0.42 ounces
1 pc. T-6 6061 Aluminum	3 Inch Wheel Used as the base structure to support the counter weight and throwing arms	63 grams 2.22 ounces
1 pc. 304 Stainless Steel	3/16" Bore Hex Adapter Functions as a bearing surface and mount for the 3 inch wheel and throwing arm	21 grams 0.74 ounces
2 pc. 5052 Aluminum	7 Hole Angle Used to create the support arm for the counterweight	13 grams 0.46 ounces

4 pc. 5052 Aluminum	13 Hole Angle Used as the legs for the support frame	25 grams 0.88 ounces
1 pc. 303 Stainless Steel	4 Inch Axle Used as the main support and fulcrum for the throwing arm assembly	14 grams 0.49 ounces
1 pc. 303 Stainless Steel	1 ½ Inch Axle Used as the main support and pivot for the counter weight	5.4 grams 0.190 ounces
4 pc. Zinc Chromate steel	Fender Washer Used to add torsional rigidity to the trebuchet structure	5 grams 0.176 ounces
4 pc. Zinc Chromate steel	#10-24 Coupling Nut Used as a stand-off to off set the sine triangle from the support frame legs.	5.5 grams 0.19 ounces
21 pc. Zinc Chromate steel	#10-24 Hex Nut Used with the machine screw to produce the clamping force to rigidly fasten the structural components	



A STATE OF THE PARTY OF THE PAR	1 pc Maple	Maple Dowel Used to construct the variable length throwing arm	
	1 pc. Lead	Counter Weight Used to power the trebuchet projectile by creating a relatively large force imbalance along the throwing arm lever system.	323 grams 11.39 ounces
	2 pc. Various Wood Species	1" Dia. Projectile Tied to the end of a sling (Fishing line)and used as the object to be thrown by the trebuchet.	
	10'	Fishing Line Used to create slings of various lengths	
Con Sun Sun Sun Sun Sun Sun Sun Sun Sun Su	2 pc.	Snap Swivel Used to attach the projectiles to the sling	
	6 pc. Various lengths	Cotter Pins Used to form the attachment between the projectile and the snap swivel	

Additional Components

These additional components can be used to modify the design parameters of the model described in the Totally Trebuchet Construction Guide. Incremental changes to the length and weight relationships of the eight design parameters can affect the performance of the trebuchet. Through a series of carefully recorded experiments, it is possible to construct a trebuchet optimized for accuracy and distance.

